

# Hardital Super Big Bang

## Technical Information

### Switch DEV1 top

TOP Autoconfig off  
BOTTOM Autoconfig Memory (\$200000 - \$9FFFFFF)

### Switch DEV1 central

ON CPU 68030  
OFF CPU 68000 (fallback)

### Switch DEV3

Harddisk Autoboot on/off

### DIP Switch

1	2	3	RAM Access Time (ns)
ON	OFF	OFF	100
ON	ON	OFF	80
OFF	OFF	ON	70
ON	OFF	ON	60

4	5	6	RAM Configuration (MByte)	RAM Type	RAM Sockets
ON	OFF	OFF	0	-	-
OFF	ON	OFF	1	256k x 4	M2,4,6,8,10,11,14,16
ON	ON	OFF	2	256k x 4	M1..M16
OFF	OFF	ON	4	1M x 4	M2,4,6,8,10,11,14,16
ON	OFF	ON	8	1M x 4	M1..M16

7	8	9	CPU Clock (MHz)
OFF	OFF	ON	16..25
OFF	ON	OFF	32..37
ON	OFF	OFF	50..55

### Jumper J1, J2

Manufacturer Test

### Jumper J3

1-2 Oscillator Q1 (general clock) / Q2 (overclock)  
2-3 Oscillator Q3 (coprocessor clock)

*Amiga Hardware World*

*Everything about Amiga hardware...*

~

<http://amiga.resource.cx>